

LOCATION OF WORK	WRITTEN BY:	APPROVED BY:	DATE:	LAST REVISION
All Schools	Lorie Carriere Jason Graham Donna Hancox	Gordon Howe	April 27, 2010	March 8, 2017

HAZARDS PRESENT	PERSONAL PROTECTION EQUIPMENT (PPE)	ADDITIONAL REQUIREMENTS
<ul style="list-style-type: none"> • Back strain • Valve breakage • Cylinder falls • Burns • Fire / explosion 	<ul style="list-style-type: none"> • Safety glasses • Protective footwear • Protective gloves • Long pants • Long sleeves • High vis. Vest • Hat 	<ul style="list-style-type: none"> • Tie back long hair

SAFE WORK PROCEDURE

PROCEDURE:

1. Don personal protective equipment.
2. Only move cylinders with protective cap installed, move carefully, do not drop cylinder.
3. Use a cylinder cart. Using a two person lift, tilt the cylinder to the side. The second person should lift the bottom of the cylinder and guide it into the cart. Lift with the legs, do not strain or twist the torso. Do not lift large cylinders without assistance.
4. Tilt the cylinder into an upright position in the cart.
5. Secure the cylinder with a chain.
6. Use the cart to move the cylinder to the desired location.
7. Lift the cylinder as indicated in #3 above to the desired location.
8. Secure the cylinder in place.
9. When working with several cylinders, each cylinder must be secured individually.

REGULATORY REQUIREMENTS

- WS&H Act W210, Section 4, 5, 7, 7.1
- Mb. Workplace Safety & Health Regulations 217/2006,
 - 2.1 Safe Work Procedures
 - 6.1 Personal Protective Equipment
 - 8.0 Musculoskeletal Injuries
 - 35.0 WHMIS
 - 36.0 Chemical Biological Substances
 - Safe Work Tip – Out Door Heat Stress