

LOCATION OF WORK	WRITTEN BY:	APPROVED BY:	DATE:	LAST REVISION
All Schools	Lorie Carriere Jason Graham Donna Hancox	Gordon Howe	April 27, 2010	March 8, 2017

HAZARDS PRESENT	PERSONAL PROTECTION EQUIPMENT (PPE)	ADDITIONAL REQUIREMENTS
<ul style="list-style-type: none"> • Sun burns • Awkward positions • Muscle strains • Trips & slips • Falls • Falling debris 	<ul style="list-style-type: none"> • Safety glasses • Protective footwear • Protective gloves • Coverall's • High vis. vest • Hat 	<ul style="list-style-type: none"> • Tie back long hair

SAFE WORK PROCEDURE

PROCEDURE:

1. Don personal protective equipment. Coverall's, safety glasses, protective foot ware and gloves will be needed.
2. Remove all obstacles from the areas below the windows.
3. Connect water lines to window wash brush unit.
4. Do not use on windy days. The washing wand is extremely long and you will not be able to hold the wand in the air.
5. Turn on the water and erect the wand up and into the air.
6. Move the wand in an up and down fashion against the window to wash the windows.
7. Allow the windows to air dry.
8. When completed, turn off the water and disconnect the hose from the end of the wand.
9. Hang coveralls up to dry.
10. Store the wand for future use.

REGULATORY REQUIREMENTS

- WS&H Act W210, Section 4, 5, 7, 7.1
- Mb. Workplace Safety & Health Regulations 217/2006, Part 16, Sections 16.1 – 16.18
 - 2.1 Safe Work Procedures
 - 6.1 Personal Protective Equipment
 - 8.0 Musculoskeletal Injuries
 - 35.0 WHMIS
 - 36.0 Chemical Biological Substances
 - Safe Work Tip – Out Door Heat Stress

